

Standalone Bill Counter

Maintenance Manual

Version No.: 1.0 Category No.: 1.0



Contents

1.	Overview	3
2.	Required Tools and Instruments for Maintenance	3
3.	Introduction to the Whole Unit.....	4
3.1	Technical Specification of the Whole Unit.....	4
3.2	Principle and function of the bill rubbing mechanism.....	5
3.3	Function of the conveyance mechanism	6
3.4	Sensors and detection of their signals Sensors and detection of their signals	6
3.5	Handling and control of signals by the single-chip computer	7
3.6	Power supply and power system.....	7
4.	Operation and Application	8
4.1	Key functions.....	8
4.2	Operation method	8
4.3	Functional setting.....	9
4.4	Machine Debugging Interface	11
4.5	Interfaces for special operational functions	18
4.6	Program downloading method.....	18
4.7	Method for uploading data.....	22
5.	Disassembly Process of the Whole Unit.....	23
6.	Installation Requirements for the Mechanical Part and Adjustment of Parameters.....	24
6.1	Installation and adjustment of the bill separating mechanism	24
6.2	Synchronization of the Friction Wheel and Feeding Wheel	26
6.3	Positioning of the “Bill Feeding Gate” Adjustment Knob	27
7.	Working Principle of the Electrical Part and Requirement of its Installation and Debugging.....	27
7.1	16 Bill feeding sensor	27
7.2	Left/Right Counting Sensors and Left/Right Penetration Sensors.....	30
7.3	Fluorescence sensor	32
7.4	Bill Receiving Sensor	34
7.5	28 Speed sensor	35
7.6	Magnetic ink sensor.....	37
7.7	Safety line detection sensor	39
7.8	Dimension Detection Sensor	42
7.9	Power Supply Parameters	46
8.	Inspection, test and fault finding for general failures	46
8.1	General failures of sensors.....	46
8.2	Bill feeding motor doesn't work	50
8.3	The main motor doesn't work or is hard to be started	51
8.4	Machine working but display abnormally	51
8.5	No response after being started.....	51
8.6	The other failures.....	51
9.	Maintenance and routine inspection	51
9.1	Weekly maintenance task.....	51
9.2	Semiannual maintenance task.....	51

1. Overview

BR-55 Series Bill Counter is a kind of intelligent high-speed discriminator for sorting and counting bank notes. It's of a standalone design. It separates bank notes with the effect of friction capability and is controlled by a single-chip microcomputer with multiple functions. In order to make the bill counter an accurate, reliable, practical and convenient product, thoughtful design and system optimization have been achieved.

This manual has provided necessary methods and suggestions to the engineers and technicians who perform repair and maintenance to BR-55 Counter.

20M oscilloscope	solder sucker	tweezers
digital multimeter	monkey wrench	diagonal pliers
wire stripper	flat screwdriver set and electric iron	long nosed pliers
Phillips screwdriver set		

Figure 1a Appearance of the Machine (front)

1. lifting handle component	6. sensor of left counter	10. bill receiving sensor
2. bill linkage baffle component	7. component of receiving wheel shield	11. right counting sensor
3. left shield	8. bill receiving wheel	12. monitor
4. film panel	9. bill receiving baffle	13. right shield
5. bed plate component		




Figure 1b Appearance of the Machine (upper part)

14. upper cover board	16. stacker sensor	18. adjusting turner
15. feeding wheel	17. bill feeding gate	43. bill feeding platform



Figure 1c Appearance of the Machine (front)

19. external display, interface for computer communication	21. power socket	23. rear upper cover board
20. nameplate	22. power switch	

2. Introduction to the Whole Unit

BR-55 Series Bill Counter consists of two parts, a mechanical and an electrical. The mechanical part includes the frame, structural parts, shell, bill rubbing mechanism and conveyance mechanism. The core of the mechanical part is the bill rubbing and conveyance mechanism. The electrical part includes various sensors and the acquisition amplifying circuit, single-chip microprocessor, power and power system for their input signals, as well as the control to input and output signals of the single-chip microprocessor, the analysis treatment to the signals and the control of such operation process.

3. 1 Technical Specification of the Whole Unit

Bill counting capability: feeds 200~300 bills; receives 200 bills

Sizes of bills: 0.05mm~0.2mm x 50mm~90mm x 120mm~175mm (thickness x width x length)

Manner of display: LCD or LED monitor

Power supply: 220V/50HZ/110V/60HZ

Power: about 40W

Environment parameters: temperature 0℃~35℃; relative humidity: 20%~80%

Volume: 290mm x 250mm x 250mm

Weight: 5.5 kilograms

Bill counting speed: 600 turns/minute, 900 t/m, 1200t/m, 1500t/m (the bill counting speeds vary according to different models and bills)




Figure 3 Diagram with upper cover, left and right shield removed

24.separation mechanism	28. speed sensor	32. upper conveyance wheel
25. feeding wheel component	29.bill receiving wheel component	33. auxiliary pinch wheel
26. friction wheel	30.conveyance baffle component	34. lower conveyance wheel
27. synchronous belt	31.control panel component	

3. 2 Principle and function of the bill rubbing mechanism

The bill rubbing mechanism consists of 15, the feeding wheel and 26, the friction wheel and 24, the separation mechanism, including two parts, the feeding and separation of bank notes. This is the key for a bill counter to be able to count bank notes accurately.

Counting of the bank notes is the process that the machine intermittently generates a friction thrust to the bank notes through rotation of the parts inside the machine. This action is jointly completed by 15, the feeding wheel and 32, the upper conveyance wheel and 26, the friction wheel and 33, the auxiliary pinch wheel.

Separation of the bank notes is the process that the machine separates a deck of bank notes into

many single bank notes, which is jointly completed by 26, the friction wheel and 24, the separation mechanism. 24, the mechanism has two functions. One is, in the progress of part rotation inside the machine, the “bill feeding gate, 17” is formed by the interaction of the rubber-free circle surface of 26, the friction wheel and 24, the separation wheel. This action only allows one bank note to go through the gate; the other is to push the bottom bank note into the machine with the joint effect of the intermittent thrust generated on the rubber surface of 15, the feeding wheel and 26, the friction wheel and the resistance generated by 34, the separation wheel which rotates in single direction and stays static intermittently.

3. 3Function of the conveyance mechanism

The conveyance mechanism includes two parts, conveyance and receiving of bank notes.

Conveyance of bank notes is jointly completed by two sets of conveyance wheels, the upper and lower wheels. The function of 32, the upper conveyance wheel, is to swiftly speed up separated bank notes. The function of 34, the lower conveyance wheel, is to enable the bank notes become flat and free of any sliding movement and then go through sensors at a certain speed to guarantee the reliability of data acquisition by the sensors.

Receiving of bank notes is jointly completed by 8, the bill receiving wheel and 9, the bill receiving baffle. 8, the bill receiving wheel makes slow-speed movement along with running of the machine; 9, the bill receiving baffle is installed behind 8, the bill receiving wheel. The high-speed bank notes passed through 34, the lower conveyance wheel, are sent to 8, the bill receiving wheel, and do mid-speed movement from there; when they move to the lower part of 8, the bill receiving wheel, will be collected and piled up at 9, the bill receiving baffle.

3. 4Sensors and detection of their signals Sensors and detection of their signals

BR55 Series Bill Counter has five groups of basic sensors and three of which are basic measurement sensors and two of which are basic control sensors. They form a basic detection system. According to difference of machine function and requirement of bank note detection, many more other kinds of detection sensors can also be added.

The basic measurement sensors include two sets. Each set consists of a 6, the left counting sensor and an 11, the right counting sensor, whose functions are to detect status of a bank note and identify position of a bank note. They are installed next to 34, the lower conveyance wheel. A pair of speed

sensors, the 28, which are for measurement of rotation speed of the machine parts, are installed in the left end of the machine.

The basic control sensors include 16, the stacker sensor and 10, the bill receiving sensor. 16, the stacker sensor is a reflective photoelectric device, which is installed onto 43, the bill feeding platform; 10, the bill receiving sensor, is a set of infrared-lit and light-sensitive parts, which is installed in the middle of 9, the bill receiving baffle.

The other measurement sensors for bank notes include H02, the fluorescent sensor, for measuring fluorescence reaction characteristic of paper quality of bank notes; H12, the magnetic detection sensor, for measuring distribution of magnetic ink on bank notes; H07, the safety line detection sensor, for detecting signal of the safety line on a bank note; H04, the sensor for detecting length and size of a bank note; H04B, the infrared ink sensor, for detecting signal of infrared ink on a bank note; these measurement sensors are installed at different positions under baffle of the lower conveyance wheel according to different application requirements and that's the approach to discriminate if a bank note is real or fake.

3. 5 Handling and control of signals by the single-chip computer

Data analysis to a bank note by the bill counter and control to running status of the machine are completed by the single-chip computer inside the machine. The whole control process is divided into few steps: handling of operational command and control signal; acquisition and calculation of information from measurement sensors and then conversion from analog quantity to digital quantity; performance of fuzzy analysis and handling to digital quantity; control to the machine according to analysis result and operational requirements.

Running of the bill counter is controlled by the single-chip computer. The single-chip computer executes pre-written program inside the machine. Therefore, in progress of actual usage, the user should strictly operate the machine according to the operation manual and this manual.

3. 6 Power supply and power system

The power supply system is a device converts 220V or 110V AC current into the DC currents required by all parts of the bill counter.

The DC currents required by all parts of the bill counter include +5V, +6V, $\pm 5V$ and +24V. +5V is to be provided and used by single chip digital circuits. $\pm 5V$ is to be provided and used by single

chip analog circuits. +24V is to be provided and used by the main motor.

Power of the bill counter is provided by Rare Earth Permanent Magnet (REPM) DC motor (main motor) and DC speed reducing motor (small motor). The small motor provides the power needed by 8, the bill receiving wheel; the main motor provides power for all other parts of the machine.

3. Operation and Application

4. 1Key functions

Sorting and counting: starts counting from 0 for each time of counting

Accumulating: starts counting from value of the first bill contact with the machine for each time of counting

Presetting number of bills: counts bills according to preset number of bills

Auto start: the machine automatically starts counting as long as bank note exist on 43, the bill feeding platform

Manual start: if 43, the bill feeding platform has any bank note, you can only start the counting by pressing the START/RESET button

Width detection: detects bank notes of different widths

Length detection: detects bank notes of different lengths

Speed adjusting: there are four levels of speeds can be selected

Contents of detection: half of a bank note; overlapping bank notes; multiple bank notes; single bank note

Methods for anti-fake identification: fluorescence identification, magnetic ink identification, safety line identification, identification with infrared characteristic, size identification (configure contents of identification according to different models)

4. 2Operation method

Connect the machine to power supply; switch 22, the power switch from OFF to ON position and then the machine will perform a 2-second self-checking. After the status becomes normal and starting of the machine, the display window will display 0 and it's ready to count.

1) Adjust the “bill feeding gate, 17”

Proper adjustment of the “bill feeding gate, 17” should be performed according to age and thickness of bills. When often encounter stop of the running during any counting action due to

re-counting of bills; or that the number of bills is too large; users should reduce number of bills at the “bill feeding gate, 17”; when fluency level becomes lower, users should increase number of bills at the “bill feeding gate, 17”. Turn in clockwise direction at the “bill feeding gate, 17” to have more bills and anticlockwise to have less.

2) Identification to the gap of the “bill feeding gate, 17”

First turn the axis of 15, the feeding wheel to enable the smooth surface of 15 to face upward; and then respectively insert two new bills into the left and right “bill feeding gate, 17” and then move them back and forth and you should feel obvious resistance; otherwise adjust the gap of the “bill feeding gate, 17”. While the adjustment range exceeds designed range, re-identify position of the adjustment knob of the “bill feeding gate, 17” according to the description in 6.3.

4. 3 Functional setting



Diagram of BR55 Operation Panel

1) Operation of basic functions

Directly enter setting status according to corresponding functions. (According to users' needs, when some machines enter certain functions, it's required to use the preset functional key to enter setting status.)

UV	ON/OFF	Fluorescence identification switch which detects fluorescence reacting characteristic of paper materials of bank notes.
MG	ON/OFF	Magnetic ink identification switch which detects the magnetic ink characteristic of a bank note.
MT	ON/OFF	Safety line identification switch which detects the magnetic or metal characteristic of safety line on a bank note.
DD	ON/OFF	Width detection switch for detecting width dimension of a bank note.
WD	ON/OFF	Length detection switch for detecting length dimension of a bank note.
DEN	1~16 级	Grade setting key for detecting grade of repeated bill; choose different repeated bills for identification of sensitivity.
SP	600/900 /1200/1500	Counting speed setting key for selecting different rotating speed.
ADD	ON/OFF	Sort and count/accumulate switch for; select display manner for showing counting result.
MUL	ON/OFF	Manual/Auto switch for selecting work mode of the machine.
EUR	ON/OFF	Euro (currency) selection key for selecting the identification function for coding of safety line for Euro bank notes.
VAL	ON/OFF	Selection key for sorting and counting certain amount.
CLR		Remove key. Remove currently sorted and counted number of bank notes and number of preset bills.
START		Start/Reset key for return from parameter setting status; remove contents on the display window for counting result; manual bill counter machine is now started.

2) Functional operation for parameter setting

Use the setting key, which is for presetting number of bills to be counted, to enter the password 127, and then press relevant keys to enter the operation of parameter setting. You can set sensitivity grade here. Smaller number, higher sensitivity, high capability for identifying fake bank note, higher possibility of wrong report. When the sensitivity grade is set to be “0”, corresponding identifying functions are turned off.

UV	Grade 0~16	Fluorescence identifying sensitivity, Grade 0~16
MG	Grade 0~16	Magnetic ink identifying sensitivity, Grade 0~16
MT	Grade 0~16	Safety line identifying sensitivity, Grade 0~16
DD	Grade 1~16	Width detecting sensitivity, Grade 1~16
WD	Grade 1~16	Length detecting sensitivity, Grade 1~16

Note: sensitivity grades of some models are different from the table above, which won't be

described here.

3) Operation for the function of preset number of bills

Different preset numbers of bills to be counted can be preset using Key 0~9 for their presetting function; the machine stops when present number of bills is counted and sorted

4. 4Machine Debugging Interface


There are two debugging interfaces according to different models

1) The fist kind of debugging interface


Includes memory data interface, sensor data interface and interface of dimensional detection data

a) Memory data interface

Keep pressing 1 until the machine enters its debugging interface; M status is the default when entering the debugging interface, namely the memory data interface;



In this status, press the START/RESET key and enter the waiting status for reading and accessing of data; and then press 2 or 3 to switch the two memory data windows and then the memory data will be accessed and read on the screen;



In the memory, positions of data are shown below:

MD1	MD2	MD3	MD4	MD5	MD6	MD7	MD8	MD9	MD1 0	MD1 1	MD1 2
MD1	MD1	MD1	MD1	MD1	MD1	MD1	MD2	MD2	MD2	MD2	MD2

3	4	5	6	7	8	9	0	1	2	3	4
MD2	MD2	MD2	MD2	MD2	MD3	MD3	MD3	MD3	MD3	MD3	MD3
5	6	7	8	9	0	1	2	3	4	5	6

MD3	MD3	MD3	MD4	MD4	MD4	MD4	MD4	MD4	MD4	MD4	MD4
7	8	9	0	1	2	3	4	5	6	7	8
MD4	MD5	MD5	MD5	MD5	MD5	MD5	MD5	MD5	MD5	MD5	MD6
9	0	1	2	3	4	5	6	7	8	9	0
MD6	MD6	MD6	MD6	MD6	MD6	MD6	MD6	MD6	MD7	MD7	MD7
1	2	3	4	5	6	7	8	9	0	1	2

Meaning of data at some key positions:

Position	Data Content	Remark
MD1	Par value codes of Euro	E1=5 Euros E2=10 Euros E3=20 Euros E4=50 Euros E5=100 Euros E6=200 Euros E7=500
MD2	Par value codes of Euro	D1=5 Euros D2=10 Euros D3=20 Euros D4=50 Euros D5=100 Euros D6=200 Euros D7=500
MD3	Par value codes of Euro	C1=5 Euros C2=10 Euros C3=20 Euros C4=50 Euros C5=100 Euros C6=200 Euros C7=500 Euros
MD4	Number of safety line	
MD5	UV value of the last bank note	
MD6	Standard value of UV	
MD7	High position of left magnetic data for Model 4011 Maximum value of left counting sensor for Model 6015	
MD8	Lowest position of left magnetic data for Model 4011 Mid value of left counting sensor	

	for Model 6015	
MD9	High position of right magnetic data for Model 4011 Minimum value of left counting sensor for Model 6015	
MD10	Low position of right magnetic data for Model 4011 Maximum value of right counting sensor for Model 6015	
MD11	Number of left magnetic pulses for Model 4011 Mid value of right counting sensor for Model 6015	
MD12	Number of right magnetic pulses for Model 4011 Minimum value of right counting sensor for Model 6015	
MD13	Codes for par value	
MD14	Codes for Euro par value	
MD15	Width codes for par value	
MD16	Length codes for par value	
MD17	High position of data for rotation speed of machine parts	
MD18	Low position of data for rotation speed of machine	
MD19	Data indicates lean of bank note	
MD20	Data for lean of bank note	
MD23	Data for overlapping bills	
MD24	Data for overlapping bills	
MD30	Standard value of length	
MD31	Data for the length of the last bill	
MD33	Standard value of width	
MD34	Data for the width of the last bill	
MD35	Categories of errors for shutdown of machine	


MD36	Sequential number for error data	
MD37	Maximum value of left counting sensor for Model 4011 High position of left magnetic data for Model 6015	
MD38	Mid value of left counting sensor for Model 4011 Low position of left magnetic data for Model 6015	
MD39	Minimum value of left counting sensor for Model 4011 High position of right magnetic data for Model 6015	
MD40	Maximum value of right counting sensor for Model 4011 Low position of right magnetic data for Model 6015	
MD41	Mid value of right counting sensor for Model 4011 Number of left magnetic pulses for Model 6015	
MD42	Minimum value of right counting sensor for Model 4011 Number of right magnetic pulses for Model 6015	

After the debugging, press 1 key to enable the debugging interface to enter R status; press START/RESET key to exit debugging status.

b) Sensor data interface

Keep pressing 1 until it enters the debugging interface; M status is the default when first enter the debugging interface; press 1 again to enter S status, which is the sensor debugging

interface;



In this status, press START/RESET key to enter the reading and access interface of sensor data.



Positions of sensor data are shown below:

M		D		S		J		R	
SD1		SD2		SD3		SD4		SD5	
SD7		SD8		SD9		SD10		SD11	


Meaning of data at key positions:

SD1	UV sensor data
SD2	Data of left penetration sensor
SD3	Data of left counting sensor
SD4	Data of right counting sensor
SD5	Data of right penetration sensor
SD8	Data of safety line sensor
SD9	Data of left magnetic ink sensor
SD10	Data of right magnetic ink sensor




After debugging, press 1 and enable the debugging interface to enter R status and then press START/RESET to exit the debugging status.

c) Dimension detection data interface

Keep pressing 1 until the machine enters the debugging interface; M status is the default status when it first enters the debugging interface; press 1 again and enter J status, namely the debugging interface for dimension sensor;



In this status, press START/RESET key and enter the reading and accessing interface of dimension detection data; press 2, 3, 4 and 5 keys to switch among the five pages of A, B, C and D.



Positions and significance of the four pages are shown below:

Page A:

A	AD1	AD2	AD3	AD4	AD5	AD6	AD7	AD8
A	AD9	AD10	AD11	AD12	AD13	AD14	AD15	AD16
A	AD17	AD18	AD19	AD20	AD21	AD22	AD23	AD24

Page B

B	BD1	BD2	BD3	BD4	BD5	BD6	BD7	BD8
B	BD9	BD10	BD11	BD12	BD13	BD14	BD15	BD16
B	BD17	BD18	BD19	BD20	BD21	BD22	BD23	BD24

PageC:


C	CD1	CD2	CD3	CD4	CD5	CD6	CD7	CD8
C	CD9	CD10	CD11	CD12	CD13	CD14	CD15	CD16
C	CD17	CD18	CD19	CD20	CD21	CD22	CD23	CD24

D 页面: Page D:

D	DD1	DD2	DD3	DD4	DD5	DD6	DD7	DD8
D	DD9	DD10	DD11	DD12	DD13	DD14	DD15	DD16
D	DD17	DD18	DD19	DD20	DD21	DD22	DD23	DD24

Among them, Page A and B represent the data detected by the left sensor; A represents the data detected from the left to the side by the left dimension sensor; B represents the data detected in the middle by the left dimension sensor;

Among them, Page C and D represent the data detected by the right sensor; C represents the data detected in the middle by the right dimension sensor; D represents the data detected from the right to the other side by the right dimension sensor;



After debugging, press 1 to enable the debugging interface to enter R status; press START/RESET key to exit the debugging status.

2) The second kind of debugging interface

Includes memory data interface, sensor data interface, data interface of detected dimension;

a) Keep pressing ADD key for 3 seconds to enter the memory data interface; press 1 or 2 to switch the two memory data windows; the operation method and display contents for memory interface are the same as 4.4 1) a).

After the debugging, press START/RESET key to exit the debugging status.


- b) Keep pressing MUL key for 3 seconds to enter the sensor debugging interface; adjust corresponding potentiometers on the main control panel to see parameter changes; the operation method and display contents for the sensor debugging interface are the same as 4.4 1) b).

After the debugging, press START/RESET key to exit the debugging status.

- c) Keep press 1 for 3 seconds to enter the display interface for dimension sensor; switch among the four pages by pressing 1, 2, 3 and 4 (or 2~5); the operation month and display contents for the debugging interface of dimension sensor are the same as 4.4 1) c).

4. 5 Interfaces for special operational functions

- a) Keep pressing the 0 key for 3 seconds to display version number, as shown below



Position and meaning of data:

Software Version				
Control	VD1	VD2	VD3	VD4
Display	VD5	VD6	VD7	VD8

Among them, Control represents version number of control software, Display represents version number of display software; see the meanings of data below:

Data Code	Meaning
VD1,VD5	Critical revision number of version
VD2,VD6	Partial revision number of version
VD3,VD7	Chip code
VD4,VD8	Model code

- b) After appearance of error, keep pressing ADD key for 3 seconds to display memory data and view relevant contents.


4. 6 Program downloading method (this function is only available for the 4011, 6011 and 6015 motherboards)

- 1) The machine can perform remote downloading. Required devices: PC computer, DB9 serial cable


- a) Use DB9 serial cable to connect the bill counter with a computer
- b) Start the PC and bill counter
- c) Install the download&upload downloading program; installation process as general Windows program

2)Download program: frist check if the jumper on the control panel is in its download status:


- a) dsp4011_D control panel; connect the two bonding pads at the right side of J1 and connect the other two at the right side of J2.



- b) Connect the two jumpers of dsp4011_E and dsp4011_On control panels onto them



- c) Connect the L04-1.40E/D/C jumpers under them




- d) Start the DOWNLOAD software
- e) Judge if the motherboard program to be downloaded is already downloaded: after empowering the motherboard, if the program indicator to the left keeps blinking, the program is already downloaded; otherwise not.
- f) If this batch of motherboard program does not contain downloaded ones, directly proceed the (g) operation; otherwise, as shown on the diagram below, click on the Handshake button.




After successful handshake (the program indicator on the motherboard will go off)

- g) As shown below, single click the DOWNLOAD button at the right



h) This dialogue will then pops up. Select the HEX file to be downloaded and then single click the Open button.



i) Start downloading software




3) Download with a laptop

a) Connect the transmission cable USB TO RS232 with the PC, as shown below:



- b) Find the COM port (com 3 or 4) assigned for USB by the PC on the Device Manager interface.
- c) Open the Download interface.
- d) Click on the Config option.
- e) Modify Port option and make it be accordant with the assigned COM port, click OK and then close the Download interface.
- f) Restart the software and perform the downloading as 4.6 2).

4. 7Method for uploading data



Upload a file

When uploading a file, you need to enter or select file name of the file to be uploaded; extension name of the file to be uploaded should be (but not limited to) .DAT; you can select a file name or enter a file name in the Name of File box; when the input file name does not include an extension name, the program will automatically add .DAT to it.

If the file is already there, the system will prompt the following message.



If you select YES, then the existing file will be overwritten and will not be recovered. We advise you to first back up the existing file and then overwrite it unless the file is no longer needed. If the file is not already there, then it will be created. After confirming for all of these, the program will start reading and accessing the built-in program inside the bill counter and store it into the file.

4. Disassembly Process of the Whole Unit

- 1) Unscrew the two M4 x 8 bolts on 23, the rear upper cover board; remove 23; give force upward and take off 14, the upper board; unscrew M3 screw on the two side boards 401.407 with screw driver set; loosen the two shields by removing the 4 M4 x 8 bolts; take off the left and right shields 3.13.
- 2) Unplug all connector plugs or pins on the control panel and take off the control panel.
- 3) Use screw driver set to loosen the four mounting bolts at both ends of the panel component and take off the panel component.
- 4) Loosen the two M4 x 8 bolts under 9, the bill receiving baffle; take off 9, the bill receiving baffle and the bill receiving shield.
- 5) Remove the two M4 x 8 bolts at both ends of the separation mechanism and take off 24, the separation mechanism.
- 6) Loosen the 4 M3 x 12 bolts at both ends of the rear-lower cover board; pull out the board; unplug connector plugs connected with the power supply panel; remove the 2 M4 x 8 bolts of the installed transformer on the bottom; take off the power supply component.
- 7) Remove two M4 x 8 bolts of the installed small motor on the bottom; unplug connector plugs on the power supply panel, which are connected with the small motor; take off 8, the bill receiving wheel.
- 8) Use a flat screwdriver to remove the E ring at both ends of the feeding component; take off

- 27, the synchronous belt; remove the small auxiliary wheel; take off the feeding component
- 9) Remove the M5 bolt at the left end of 34, the lower conveyance wheel; take off tachometer disc; take off 27, the synchronous belt; remove the small belt wheel
- 10) Remove the belt wheels and E rings at both ends; remove the bolts at both ends of the conveyance baffle; remove the bolts at both sides of the lower baffle; remove all the other transmission shafts.
- 11) Remove the other installation parts.


5. Installation Requirements for the Mechanical Part and Adjustment of Parameters

6. 1 Installation and adjustment of the bill separating mechanism (see Figure 9 and 10)

The function of 24, the bill separating mechanism, is to separate a deck of bank notes into single ones and send them into the machine. This is realized by the joint effect of the intermittent friction generated by 26, the rotating friction wheel, and the direction-reversed resistance generated by 34, the separating wheel.


In process of the work, the rubber part of 26, the friction wheel, and B, C, the side gaps of 34, the separating wheel, will affect the friction thrust; therefore, in process of the debugging, it's required that the gap of 26, the friction wheel, and 34, the separating wheel, should be equal, namely, $B=B'$ and $C=C'$.

If process of the work, the gaps of 26, the friction wheel, and 34, the separating wheel, normally, A and A', will affect the separating resistance; if the distances of A and A' are unequal, it will cause no lean and revulsion of a bank note. Therefore, the gaps (the bill feeding gate, 17) formed by the rubber-free part of the two sets of friction wheels, 26, and 34, the separating wheel, should be equal, normally, $A=A'$.



32.adjusting spring	35.spacing board	38.pinch wheel part	41.adjusting bolt
33.bracket adjusting base	36.bracket die cast	39.auxiliary pinch wheel part	
34.separating wheel	37.bracket fixed axis	40.upper baffle	

Figure 9 Position Drawing of 24, the bill separating mechanism



34. separating wheel	26.friction wheel	42.rotation testing wheel
----------------------	-------------------	---------------------------

Figure 10 Position and Gap of the Friction Wheel and 34, the separating wheel

Installation and adjustment of 24, the bill separating mechanism

Installation and adjustment method:

Alignment of 24, the separating mechanism: loosen the fixed bolts of the spacing rings at the

left of the fixed axis to 24, the separating mechanism; move 24 leftward and rightward and make sure the whole parts are in good alignment and then fasten and fix them. Adjustment of the side gaps of 34, the separating wheel and 26, the friction wheel: loosen the two bolts of 34, the fixed separating wheel; move 34 leftward and rightward and make it that the rubber part of 26 equals to the side gap of 34; and then fix and fasten them. The left and right gaps of the “bill feeding gate, 17” are the same; turn the adjustment knob for bill thickness to enable the “bill feeding gate, 17” to let exactly one bill to go through; test status of the left and right gaps; base on test result, loosen the bolts on the fixed bracket (normally loosen 3 and the fourth stay still), knock gently until it meets installation needs; finally, fix and fasten the bolts; certain level of skill is required for doing the work above, it requires many times of tests and adjustment.

6. 2 Synchronization of the Friction Wheel and Feeding Wheel

The function of 15, the feeding wheel, is to provide an additional friction thrust to 24, the bill separating mechanism and hence enable the bill to enter 24, the separating mechanism in good order. The additional friction thrust is realized by the block rubbers on 15, the feeding wheel. If move action time of the block rubber forward, the additional friction thrust effect will become larger; if the time is delayed, the additional friction thrust effect will become smaller. Therefore, position of the block rubber functions to perform fine adjustment to the friction thrust of the bill rubbing mechanism.

Installation and adjustment method:

Keep turning 15, the feeding wheel, along the bill incoming direction, until the highest point from Point A to surface of 43, the bill feeding platform, has been reached; and the distance between the tangent point of 26, the friction wheel and 34, the separating wheel, and the rubber part of 26, the friction wheel, becomes 3~5mm; this can be achieved by adjusting position of the serrated belt.




Figure 11 Position Drawing of 26, the Friction Wheel and 15, the Feeding Wheel

6. 3Positioning of the “Bill Feeding Gate” Adjustment Knob (see Figure 9)

Installation and adjustment method:

Fix the positioning bolt on the adjustment knob in advance; adjust the gap of the “bill feeding gate, 17” with a bank note; when a bank note passes through the gate, obvious resistance should be felt; and then loosen its fixed bolts; position the small dot of the knob at the highest point and fasten it. After installation of 14, the upper cover board, if the position has some change, re-adjustment needs to be done.

6. Working Principle of the Electrical Part and Requirement of its Installation and Debugging

In this part of the electrical schematic diagrams, the code begins with “M-“ means this component locates in the control panel section; the one begins with “D-“ means this component locates in the display panel section; the one begins with “P-“ means this component locates in the power supply panel section; the one begins with “UVP-“ means this component locates in the UV power supply panel section; the one begins with “S-“ means this component locates in the sensor section.

7. 1 Bill feeding sensor

1) Description of Working Principle

The stacker sensor is installed on the bill feeding platform, which is used for detecting

placement status of the bank notes on the bill feeding platform. It's a reflective light chopper formed by an infrared illumination and an infrared receiver. Turn on of the infrared illumination is controlled by the V_I modulation signal; the infrared receiver identify if any bank note exists on the bill platform by detecting the status when the infrared modulation light sent out by the detecting illumination is reflected by the bill.

2) Electronic schematic diagram and oscillogram





Figure 12 Electric Schematic of the Bill Feeding Part



When there's no reflection from bank note $V_b \leq 80\text{mV}$





Figure 13-1 Waveform for each point when no reflection from bank note



Vb has the peak value of 750-800mV when use black object for reflection




Figure 13-2 Waveform of each point for reflection by black object

Figure 13 Waveform of the bill feeding part

3) Debugging

A. Debugging instruction

Turn the potentiometer RA1 in clockwise direction and V_a , the voltage generated by photo current should increase; Turn the potentiometer RA1 in clockwise direction and V_a , the voltage

generated by photo current should decrease and V_b should change accordingly as V_a changes.

B. Debugging Steps

- a) First turn the potentiometer RA1 to the end in anti-clockwise direction; in irradiation of strong light, when the stacker sensor is not covered, fluctuation quality of the reflection signal received by the sensor, V_b should be $\leq 80\text{mV}$. At this moment, the machine can't start.
- b) When placing a wholly black object onto the sensor surface, adjust RA1 potentiometer and make the peak value of the reflection signal generated by the sensor, V_b be $750\sim 800\text{mV}$; now the peak value of V_c should be $\geq 4.3\text{V}$ and the machine should be normally running.
- c) If test with bank notes, it should run normally.

7. 2 Left/Right Counting Sensors and Left/Right Penetration Sensors

1) Description of Working Principle

The left and right counting sensors are a kind of infrared sensor. They're located on both sides of the lower conveyance wheel. They're for detection of status signal of bank notes. The left and right counting sensors consist of two pairs of infrared emission and receiving sensors, which are respectively installed at both sides of the bill conveyance path; when a bill passes through a counting sensor, the counting sensor will have parameter change to generate change of electric signal and hence be able to perform bill counting and discrimination of overlapping bills. The left and right penetration sensors are absolutely the same sensors as the left and right counting sensors. They're installed in the upper part of the path at the same horizontal position as UV. Its function is to detect the position signal when a bank note passes through UV sensor. It can also be used to detect the penetration characteristic of a bank note.

2) Electric schematic diagram and oscillogram






Figure 14 Electric Schematic of the Infrared Sensors



Waveform when no passing through of bank note



Waveform when there's continues passing through of bank note

Figure 15 Output oscillogram for the infrared sensors

3) Installation requirement

Adjust installation positions of the left and right counting sensors and penetration sensors and make the output voltage of the receiving tube be $V_a \geq 4V$ when no bank note passes through any counting sensor.

4) Debugging


A. Debugging instruction

Adjusting the RA3 potentiometer can change sensitivity of the left counting sensor; clockwise to decrease and anti-clockwise to increase;

B. Debugging steps

- a) Enter the sensor debugging interface shown below according to the description at

4.4.b



- b) Use standard 80g white coated art paper and place it at a corresponding position

which interact with the path of the counting sensor; and then make base line of the paper and the base line of the lower conveyance baffle at the same surface and at the same level; and then adjust corresponding potentiometers to make 3C or 3D the data of SD2, SD3, SD4 and SD5

c)After full adjustment, take out the paper and then press the 1 key for few times until the R option is selected and then press START/RESET key to exit.

Note: the parameters above (3C or 3D) has something to do with specification of the coated art paper; in actual operation, you can test the paper to be tested on an adjusted machine and identify its testing value and then use this testing value as a benchmark for adjustment of the machine to be done.


The debugging method for the two pairs of penetration sensors and the infrared counting sensors on the other side are the same.

7. 3 Fluorescence sensor


1) Description of working principle

The Fluorescence sensor locates in the middle of the lower conveyance wheel or the middle of dimension sensor. It's for identifying the fluorescence reaction of a bank note when it's in a UV light. It consists of an UV light emission device and a fluorescence receiving device. UV light emission device is oscillated via the 800V/50KHZ DC current generated by its step-up oscillatory circuit, which activates the UV light to work. The UV light is installed in a confined space to emit ultraviolet light. The fluorescence receiver device consists of multi-layer glass and silicon photo cell. Multi-layer glass forms an optical filter; the silicon photo cell detects fluorescence signal generated from a bank note.

2) Electric schematic diagram and oscillogram




Electric schematic for UV emission




Electric schematic for fluorescence receiving

Figure 16 Electric schematic of the fluorescence receiving part



Waveform when fluorescence reflection exist (2 is the waveform when sorting and counting the testing paper which has a little fluorescence characteristic)



Waveform when no fluorescence reflection (2 is the waveform for counting the real bank notes)

Figure 17 Waveform change for fluorescence test

3) Debugging

A. Debugging instruction

Adjusting the RA6 potentiometer can change the fluorescence reflection sensitivity of the machine; clockwise to decrease and anti-clockwise to increase.

B. Debugging steps

- a) Adjust the fluorescence grade into Grade 1 according to the instruction in 4.3.2.
- b) Use bank notes and let the bill counter count 500 pieces and the wrong reporting of fake note should be within 1 to 3 times. If it's larger than 3 times, you should adjust the RA6 fluorescence to lower its sensitivity. If there's no wrong reporting, increase the sensitivity. Recount the bank notes until it has met the requirements.
- c) Adjust the fluorescence grade into Grade 6 and there's should be no wrong reporting for counting 1,000 bank notes.
- d) If there's any wrong reporting, lower the sensitivity; repeat above steps until it has met the requirements.

7. 4 Bill Receiving Sensor

1) Description of working principle

The bill receiving sensor locates inside the bill receiving bracket, which is for detecting if there's any bank note exist on the bill receiving platform. It consists of infrared emitting diode and infrared receiving sensor. The infrared emitting diode generates infrared signal and the infrared receiving sensor receives the signal sent out from the infrared emitting diode.

2) Electric schematic diagram and oscillogram






图 18

Figure 18 Electric Schematic for the Bill Receiving Part



$U_a > 4.3V$ when there's no bank note



$U_a < 0.3V$ when there is a bank note

Figure 19 Change of Waveform for Bill Receiving

3) Installation requirement

When being covered with a bank note, $U_a > 4.3V$; when being not covered, $U_a < 0.3V$

7. 5 Speed sensor

1) Description of working principle

The speed sensor locates next to the tachometer grating at the left end of the lower conveyance axis. It's for detecting speed of the bill counter. It consists of infrared emitter and receiving germinate transistors. Grating of the tachometer disc, along with rotation of the machine, makes parameters of the speed sensor change periodically and hence detect speed of the bill counter.

There are two configurations for speed sensors according to different machine model. The first is a tachometer disc of 19 teeth and the other 157. The 19-tooth tachometer disc generates signal of rotation speed along with running of the matching. It's for testing the rotation status of the machine. The 157-tooth tachometer disc generates sync pulse of rotation speed along with running of the machine, which goes through a doubling circuit, and then further increase number of sync pulses. This is for precise measurement and positioning of status of a bank note.

2) Electric schematic diagram and oscillogram




Figure 20 Electric schematic and oscillogram of the 157-tooth tachometer disc




Figure 21 Electric schematic and oscillogram of the 19-tooth tachometer disc

3) Installation requirement

When the tachometer grating is not covering the sensor, $U > 4.3V$ (normally, the peak value of U on the work flow should be $> 4.3V$); when the tachometer grating is covering the sensor, $U > 0.3V$ (normally, the valley value of U on the work flow should be $> 0.3V$);

7. 6 Magnetic ink sensor

1) Description of working principle

The magnetic ink sensor is a kind of magneto-dependent sensor, which is installed under the component of the lower conveyance wheel. It's for detecting ink characteristic of designated position on a bank note. When a bank note with magnetic ink goes through a sensor, there will be a tiny change for the output signal of the magnetic ink sensor; the signal of such change will be amplified through the amplifying system and transmitted to the detection system. The detection system will judge weather it's a real bank note or note according to the signal characteristic of the magnetic ink.

2) Electric schematic and oscillogram






Figure 22 Electric schematic of the magnetic ink detection part



Noise signal when there's no paper



Waveform when a bank note with magnetic ink goes through the magnetic sensor

Figure 23 Waveform change for magnetic ink detection

3) Installation requirements

- The gap between surface of the sensor and pinch rim of the magnetic head should be 0.1~0.15m. Test it with a bank note and obvious resistance should be felt.
- When there's no paper pass through the sensor, output of L_CT should have noise signal only and the noise $\leq 200\text{mV}$.




Figure 24 Schematic diagram of assembly for the magnetic ink sensor

4) Debugging

A. Debugging instruction

a) Turn RA9 in clockwise direction and reduce sensitivity of magnetic detection of the left magnetic ink sensor; turn in anti-clockwise direction and increase the sensitivity.

b) When there's paper with magnetic ink pass through the sensor, the waveform change for L_CT output will be shown as Figure 23. When there's no paper with magnetic ink pass through the sensor, there will be no magnetic signal for the L_CT output but noise.

B. Debugging steps

a) First adjust the detection sensitivity of the magnetic ink sensor to the lowest point; and then use a testing bank note without magnetic ink to test the bill counter and there's should be no alarm; after that, slowly increase the detection sensitivity of the magnetic ink sensor until the alarm for bank note with magnetic ink activate and the machine should stop then.

Remark: the installation and debugging method for the other side of the magnetic ink sensor is the same.

7. 7 Safety line detection sensor

1) Description of working principle

Safety line detection sensor is also a kind of magnetic detection sensor. It's installed in the lower part of the lower conveyance baffle. It's for detecting the safety line of a bank note or the magnetic characteristic of the middle area of a bank note. When a bank note with magnetic ink passes through the sensor, there will be a tiny change in output of the sensor and the signal for this change will be amplified by the amplifying system and sent to the detection system. The detection system will judge if the bank note is real or fake according to characteristic of the

signal from the magnetic ink.

2) Electric schematic diagram and oscillogram






Figure 25 Partial Electric Schematic of the Safety Line Detection



Noise signal when there's no paper



Waveform for testing of 200 Euros

Figure 26, Partial Waveform Change for Safety Detection

3) Installation requirement

a) The gap between surface of the sensor and pinch rim of the magnetic head should be 0.1~0.15m. Test it with a bank note and obvious resistance should be felt.

b) When there's no paper pass through the sensor, output of L_CT should have noise signal only and the noise $\leq 200\text{mV}$.




Figure 27 Schematic Diagram of Assembly for Safety Line Detection Sensor

4) Debugging**A. Debugging Instruction**

- a) Turn RA11 in clockwise direction to lower sensitivity of the safety line detection; turn RA11 in anti-clockwise direction to increase the sensitivity.
- b) When a bank note with magnetic ink passes through the sensor, the D_CT output will have the change shown as Figure 26. When a paper without magnetic ink goes through the sensor, there will be no magnetic signal for the D_CT output but noise.

B. Debugging steps


- a) First decrease sensitivity of the safety line detection; keep decreasing until wrong reporting happen when test with a bank note with safety line.
- b) Increase sensitivity of the safety line detection; keep increasing until the wrong reporting disappears. After that, use the bill counter to count bank notes without safety lines and the counter should alarm.
- c) Repeat these for many times according to a) b) until a real bank note can pass through without alarm and alarm when a fake one passes through.

7. 8 Dimension Detection Sensor


1) Description of working principle

The dimension detection sensor is installed on both sides of the conveyance path. It's for verifying dimension of a bank note. It consists of an emitter sensor and a receiver sensor. The emitter sensor sends out light signal through infrared illumination array, which penetrates a bank note or directly arrives in the receiver sensor. The detection system judges dimension of the bank note according to characteristic of the signal it received.


2) Electric schematic diagram and oscillogram



Emitting principle of the dimension detection




Principle of the dimension detection



Signal process principle of the dimension detection


Figure 28 Schematic diagram of the dimension detection part

WD-L




Waveform when no paper covers the sensor

WD-L



Waveform when uses a bank note partially cover the dimension sensor



Waveform when uses a bank note fully cover the dimension sensor

Figure 29 Waveform of dimension detection

3) Installation requirements

- Enter the display interface for dimension sensor according to requirement of 4.4 c.
- Decrease sensitivity of dimension sensor and achieve the value of 80 also when the sensor is not covered with any bank note.
- Move the emitting or receiving part of the dimension sensor and select a position of average and larger value for final installation.
- Repeat the adjustment for few times until the above requirements are met.

4) Debugging

- The first kind of debugging month (only for usage of the circuit boards of dsPIC30F4011_E, dsPIC30F4011_G and dsPIC30F6010_B1)


A. Debugging instruction

Adjusting the RA7 potentiometer can change sensitivity of the left dimension sensor; clockwise to decrease and anti-clockwise to increase.

Adjusting the RA8 potentiometer can change sensitivity of the right dimension sensor; clockwise to decrease and anti-clockwise to increase.

B. Debugging steps

- First remove any bank note in the path and make sure there's no bank note on the path.
- Enter the debugging interface of the dimension sensor according to description of 4.4.c.



M		D		S		J		R	
X0	X1	X2	X3	X4	X5				
Y0	Y1	Y2	Y3	Y4	Y5				
Data of Row 1 shows parameters of the left dimension sensor; data of Row 2 shows the right dimension sensor; among them; X0=A3 and Y0=B3 is the mark bit.									
X1, Y1 is the saturated magnitude of voltage of the sensor									
X2, Y2, the maximum unsaturated and voltage difference of the sensor									
X3, Y3, number of the unsaturated points of the sensor									
X4, Y4, number of bad points of the sensor									
X5, Y5, has empty value and temporally not being used									

c) According to the sequence from left to right, one by one, adjust the data; first adjust the X1 parameter; after meeting the parameter requirement; this must be done: in the situation that the X1 parameter has met the requirement, adjust the X2 parameter; following this example and adjust the other parameters. Here are requirements for all the parameters:

(X1,Y1)>B0-----otherwise adjust the potentiometer in anti-clockwise direction

05<(X2,Y2)<30-----clockwise to decrease and anti-clockwise to increase

0F<(X3,Y3)<1F----clockwise to decrease and anti-clockwise to increase

(X4,Y4)<03 -----after meeting requirements for all the above parameters, if the requirement of this item cannot be met, replace the sensor.

After full adjustment, keep pressing the 1 key and select the R option and then press START/RESET key to exit.

2. The second kind of debugging method (universally for use by the L04-1.40D, L04-1.40E and L04-1.15B motherboards)

A. Debugging instruction

Adjusting the RA4 potentiometer can change sensitivity of the left dimension sensor;

clockwise to decrease and anti-clockwise to increase.

B. Debugging steps

- a) Enter the debugging interface of the dimension sensor according to instruction at 4.4.c.
- b) Perform fine adjustment of RA4 and make the AD1-AD24 and BD1-BD24 values on the A and B pages into a value higher than 70; besides, values of the saturated points for the A and B pages should be 93 and 94 and there are total 1 to 5 for these.

Remark: the debugging method for the other side of the dimension sensor is the same.

7. 9Power Supply Parameters

- 1) Input voltage of transformer $220V \pm 10\%$ /50HZ or $110V \pm 10\%$ /60HZ.
- 2) Output voltage of transformer 9V,9.5V,21V,25V.
- 3) Voltage sent out from the power panel to the control panel $5V \pm 5\%$ (digital power supply), $\pm 5V \pm 5\%$ (analog power supply).
- 4) Working voltage for the UV light of the power panel $6V \pm 10\%$; high frequency output 800V, 50KHZ.
- 5) Voltage for running of the small motor 9V (LD60E1B,98004G power panel) or 6V (POWER0404-E power panel)
- 6) Voltage for running of the main motor 10V~20V (speed adjustment).

8 Inspection, test and fault finding for general failures

8. 1General failures of sensors

1) Failure of 16, the bill feeding sensor

Phenomenon: start the machine and it displays FE1 (CHECK HOPPER SENSOR) or automatically starts when there's no bank note on the machine.

Method of fault finding:

Step 1: check if 43, the bill feeding platform (on 16, the bill feeding sensor) is covered by any object.

Step 2: check if light of the working environment is too strong.

Step 3: start the machine and check if FE1 displays; or if the matching starts automatically

when there's no bank note on it and if it can't start when there's bank note; adjust RA1 in clockwise direction.

Step 4: check if the welding line on 16, the bill feeding sensor is in an open circuit.

Step 5: it should be failure of parts at 16, the bill feeding sensor.

2) Failure of the left and right counting sensor

Phenomenon: start the machine and it displays CHECK LOWER LEFT IR, CHECK LOWER RIGHT IR; or it appears abnormally during bill counting process.

Method of fault finding:

Step 1: check if any bank note or paper is covering surface of 11, the left and right counting sensor.

Step 2: check if connection of the emitting lines of the left and right counting parts, the receiving lines for the left and right counting and the control panel is loosen or has bad contact.

Step 3: after starting the machine, check the voltage between Pin 1 (red wire) and Pin 3 (white wire) of JP12, which should be about 1.2V; if there's an obvious gap for the voltage, check if the receiving lines for the left and right counting is in an open circuit (stop at the welding point); if this is normal then it should be a failure of certain part of the receiving tube.

Step 5: use standard coated art paper to cover the left and right counting tubes, and then measure the voltage between Pin 1 and Pin 3 of JP14, which should be smaller than 1.5V; if there's no change in the voltage compared to the status before the covering, check if there's any short circuit at welding points of the receiving tube; if this is normal, then it should be a failure in a certain part of the receiving tube.


3) Failure of 28, the speed sensor

Phenomenon: start the machine and it displays CHECK SPEED SENSOR.

Method of fault finding:

Step 1: check if connection of the wire of 10, the bill feeding speed sensor and control panel, tachometer circuit board (SPEED-C) is loosen or has bad contact.

Step 2: check if the installation position of 10, the bill feeding speed sensor (SPEED-C) is correct; it's required that teeth of the tachometer disc should face right opposite the sensor and can fully cover the light axis (see the attached figure).



Step 3: check if running of the main motor is normal.

Step 4: check corresponding circuits on the control panel.

4) Failure of 10, the bill receiving sensor

Phenomenon: start the machine and it displays CHECK STACKER SENSOR.

Method of fault finding:

Step 1: check if any bank note or paper is covering 10, the bill receiving sensor.

Step 2: check if the connection between the lead of 10, the tachometer bill receiving sensor and the control panel is loosen or has any bad contact.

Step 3: check that the voltage of Pin 1 of JP6 should be larger than 4.5V, Pin 2 should be 5V (voltage of power supply), Pin 3 should be about 1.2 and Pin 4 should be 0V (earth).

If the Pin 3 voltage is abnormal, the emitting tube for bill feeding should be broken; if the voltage of Pin 1 is abnormal, there should be something wrong in the emitting tube or corresponding circuits on the control panel.

Step 4: check corresponding circuits on the control panel.

5) Failure of the fluorescence sensor

Phenomenon: start the machine and it displays CHECK UV SENSOR; or it frequently displays: Suspect UV Check again.

Method of fault finding:

Step 1: check if the UV sensor is covered by any plain paper.

Step 2: adjust the RA6 potentiometer in clockwise direction.

Step 3: check if there's any problem with the corresponding circuits on the control panel.

6) Failure of the dimension sensor

Phenomenon: in progress of bill counting, it frequently displays: Suspect Length Check

again or Suspect Width Check again.

Method of fault finding:

Step 1: check the emitting lead of the length sensor; receiving lead of the length sensor and control panel; check connection and plugging of the length detecting(emitting and receiving) circuit board.

Step 2: press the 1 key and enter detection status for length detection; the value should read above 70 when there's no plain paper cover the sensor and 20~40 when there is.

Step 3: check as Step 2 describes; if certain value reads very small, certain part of the length sensor must have failure.

Step 4: if, when there's no plain paper covering the sensor, all groups of values are the same; and, the values are still the same when there's plain paper covering, or no change of the values, check the emitting lead of the length sensor; check if there's any problem with the receiving lead of the length sensor and welding of the length detecting circuit board.

Step 5: check corresponding circuits on the control panel.

7) Failure of the safety line sensor

Phenomenon: in progress of bill counting, it frequently displays: Suspect MT Check again.

Method of fault finding:

Step 1: check if connection of lead of the big magnetic head and the control panel is loosen or has bad contact.

Step 2: unplug and take off wire of the big magnetic head; check that the voltages of Pin 1 and 4 of JP25 of the control panel should be respectively about 2.5V and their earth wire and signal line there should be about -2.5V; if this is abnormal, check corresponding circuits on the control panel.

Step 3: plug wire of the big magnetic head into JP25 on the control panel; check that the Pin 1~4 voltages should be respectively about 2.5V at JP25 and the earth wire and signal line about -2.5V; if this is abnormal, the big magnetic head has problem.

Step 4: adjust the RA11 potentiometer on the control panel.

8) Failure of the magnetic ink sensor

Phenomenon: in progress of bill counting, Suspect MG Check again frequently appears.

Method of fault finding:

Step 1: check if connection of the lead of the small magnetic head and the control panel is loosen or has bad contact.

Step 2: unplug wire of the small magnetic head from the control panel, and then check if the voltages of Pin 1 and 8 at JP24 on the control panel are respectively about -2.5V and +2.5V, and their signal lines and earth wires about -2.5V and +2.5V; if they're abnormal, check corresponding circuits on the control panel.

Step 3: plug wire of the small magnetic head into JP24 on the control panel, and then check if the voltages of Pin 1 and 4 at JP24 on the control panel are respectively about -2.5V and +2.5V, and their signal wires and earth wires -2.5V; if they're abnormal, check corresponding circuits on the control panel; if the circuits are abnormal, it should be a problem of the small manager head.

9) Failure of the left and right position sensors.

Phenomenon: start the machine and it displays Left count sensor error.

Method of fault finding:

Step 1: check if connections of the double barreled emitting lead, double barreled receiving lead and the control panel are loosen or have bad contact.

Step 2: check if positive voltage of the emitting tube is about 1.2V; if the voltage is too much different, it should be a problem of the emitting tube.

Step 3: check the voltages of Pin 1 and 3 at JP7; when the sensor is covered with plain paper, adjust the RA9 and RA10 potentiometers until the voltages of Pin 1 and 3 become 0.5V; and then take out the plain paper and check if the voltage of Pin 3 is larger than 3V; if lower than 3V, replace the emitting tube or receiving tube.

Step 4: check if Pin 1 and 4 at JP7 are electrically connected with Pin 4 of the single chip.

8. 2 Bill feeding motor doesn't work

Please check output signal of the control panel and Pin 3 of JP3 of the motherboard. When the motor is working, it should be in low level ($>0.6V$); when it is not working, it should be in high level

(>3.6V). Check the power supply status. Disassemble the bill feeding shield and then check if wire of the small motor is properly plugged onto the 4JP4 of the power panel.

8. 3 The main motor doesn't work or is hard to be started

Check control signal of the main motor and output voltage status at the Pin 5 socket of JP3 on the motherboard. When the motor is working, it should be square wave. When the motor is not working, it should be high level (>3.6V). Check if the two 9014s and TIP122s on the power panel have become ineffective. Check input and output status of RIF640.

8. 4 Machine working but display abnormally

If there's interrupted display or darkened image, check if J6 (or J3J4) is well plugged or has bad contact.

If pressing of any key is ineffective, check if J5 on the display panel is well plugged; for 2 x 4 pin plug, you should plug from Pin 1.

8. 5 No response after being started

Turn off the machine immediately and check input and output requirement for the power supply section.

8. 6 The other failures

1) Shutoff protection

Turn off the power, move the machine to a place where is free of any disturbance, restart the machine.

2) Communication error

Step 1: restart the machine

Step 2: check if the connection wire is loosen or has bad contact

Step 3: check if version name of the software meets requirement of the factory setting

9 Maintenance and routine inspection

9. 1 Weekly maintenance task

Remove dust; clean dirt and ink spill.

9. 2 Semiannual maintenance task

Check worn condition of the machine

Check connection status of all plugs