







How to Install Windows 8 on VerifiveUpdaterSetup [Guide]


1. Move the mouse pointer in the lower right of the screen to display the sidebar and click Settings, as shown in the screenshot below.



2. This will open the display as basic settings, such as volume, notifications, the Power PC etc. click Edit Settings.




3. Now we are in the settings menu of your PC as you can see from the screenshot below. Now click the General button.



4. We are now in menu "Choose an Option" click Troubleshooting.




5. In the "Troubleshooting", click Advanced Options.




6. Now we are in the section "Advanced Options". Click Startup Settings.



7. In the "Startup Settings" there are a number of options that specify and optimize the Windows startup, and is at the start you need to disable the running for the signature of the driver. Press the Restart button.



8. The PC will restart and after boot you will be given a number of options to choose from. Selected the option of Startup Settings with the signing of driver control Disabled, pressing the number corresponding to the 'list (in the case shown in the screenshot below the number is 7).



9. At this point, carefully read the installation instructions Verifive Updater and then proceed with the software installation.

Warning: *it is possible that at the end of the entire procedure of installing the new firmware updater software Verifive indicates update failed, severely as it is just a bug that occurs on Windows 8 The Verifive is still updated and you can check it immediately passing a new 5 euro or a new 10 euro.*